
Minicube Flysky AFHDS-2A IBUS version quick user guide



Bind procedure:

- -Power for the Receiver board(Direct +5v to the receiver or power from Minicube F3) while holding the binding button on the Receiver board ,the Blue LED will blinking fast, this indicates the Receiver is in binding mode. Then release the binding button.
- -Turn on your radio and Set receiver mode to AFHDS 2A, then get your radio into binding mode. The blue LED on the Receiver board will turning off for a second and then starting to blinking slowly, this indicates binding successfully.

Setup in Betaflight with Minicube F3 flight controller:

Enable Serial_RX for UART3 from the Port tab in Betaflight configurator, then select RX_SERIAL from the RECEIVER Mode and set the Serial Receiver Provider to be IBUS in Betaflight Configurator.

