





L/ R Propeller installation



Please note that in accordance with the sequential control



AV Transmitter 5.8G 200MW 48ch



FR	GH	Ch							
		Ch1	Ch2	Ch3	Ch4	Ch5	Ch6	Ch7	Ch8
FR	Fr1	5865M	5845M	5825M	5805M	5785M	5765M	5745M	5725M
	Fr2	5733M	5752M	5771M	5790M	5809M	5828M	5847M	5866M
	Fr3	5705M	5685M	5665M	5645M	5885M	5905M	5925M	5945M
	Fr4	5740M	5760M	5780M	5800M	5820M	5840M	5860M	5880M
	Fr5	5658M	5695M	5732M	5769M	5806M	5843M	5880M	5917M
	Fr6	5362M	5399M	5436M	5473M	5510M	5547M	5584M	5621M

LINE 1:VDD-IN(7-24V)
LINE 2:GND
LINE 3:VIDEO-IN
LINE 4:AUDIO-IN
LINE 5:GND

SWC

- ✘ Primary flight mode : the Flight Control System comes with stabilization function, its operation is relatively stable, can not roll but suitable for beginners.
- ✘ Intermediate flight mode : the Flight Control System comes with partial stabilization function, its operation is relatively flexible, it can roll.
- ✘ Advanced flight mode : The Flight control System comes without stabilization function, its operation is very flexible, it can roll.

STABILIZE Flight Mode	INTERMEDIATE Flight Mode	ADVANCED Flight Mode
MIX Switch to "0"	MIX Switch to "1"	MIX Switch to "2"

