


Safety Precautions

- 1、 Be far away from obstacles and people, identify whether there are unsafe factors, such as high voltage wires, vehicles and people.
- 2、 Avoid playing it when you are tired, drink wine or be in bad spirit in case of accidents.
- 3、 Avoid playing it when it is windy or rainy, otherwise, the obstacles of the electronic equipments will cause danger.
- 4、 Be far away from heat sources in case of the damage of the electronic equipments or of the other components.
- 5、 Avoid playing it alone when learning it in the early stage, we suggest you to ask the experienced pilots for help before playing it.
- 6、 Check whether the equipment is normal before playing it and whether it has co-channel interference.
- 7、 Avoid touching the working motor and the airscrew, avoid touching it with your hands directly.
- 8、 Please keep the throttle rod of the remoter at the lowest point before playing it.
- 9、 When testing or adjusting the flying machine, you can dismantle the throttle rod when it is necessary, and then equip it after finishing the adjustment in case of security accident.
- 10、 Please check the installation instructions before equipping it and use it correctly with the components supplied, users should take on all the flying responsibilities of the model aircraft accidents caused by the components from other sources or reinstallation.

Safety Precautions



Product introduction

Name:x220

Wheelbase: 220mm

Weight: 340g

GMachine arm: 4mm carbon fiber

Body: 1.5mm carbon fiber

Size: 160*205mm

Motor: 2204-2300KV

ESC: BL-S 20a 2-4s

Flight controller: NAZE 32 6DOF

FPV transmitter: 5.8g 48CH 200MW

FPV camera: 2.8mm cmos 700

Propeller:5045

Recommended battery: 3S,1500mAH 25C