


Aurora instructions

Wiring instruction:

1. Insert the USB port into the mobile phone charger, power bank, computer U port, for power supply; Note that if the remote control is not sensitive and the supply current is not enough, you need to replace a larger current power supply!
2. The spectrum display uses the microphone head to collect sounds. If you want to change to audio cable, see below setting.

Introduction to the use of the remote control:

Before using the remote control, the battery grid mode of the remote control must be removed first, and the remote control should be pressed from the top down to the integrated receiving head.



Key Description:


Button 1: Aurora Spectrum Mode Description: In the spectrum mode, the default is to switch the color automatically. You can change the color mode by pressing the “+” button on the remote control. When you feel that the spectrum barely beats, please increase the output sound of the computer. When the spectrum is always in the full state, please adjust the output of the computer.

Button 2: Aurora Gradient Mode

Button 3: Water mode


Button 4: Overall gradient mode

Change audio line instructions




Voic connects one audio channel by welding.
- Through the welding ground wire.


In addition, the 104 capacitors in the figure below need to be soldered to prevent mutual interference of the microphone signals. Cut the audio cable as shown below:



The modified effect chart is as follows:



Since the audio cable is relatively thin, fix it with glue after welding. 104 capacitors removed in the figure below



The blue precision adjustable resistor above is the sensitivity of the adjustable spectrum